EX100

DESCRIPTION	PART NUMBER
AC Power Cable (2-prong cable)	1467649
Lamp (V13H010L38)	1446801
Computer VGA Cable	2110978
Audio Adapter (RCA female-3.5mm stereo)	2089445
Remote Control	1291754
VGA Component cable	2118180
USB cable	2109210
Soft (black) Carrying Case with shoulder strap	1440601

Order user replaceable parts from an Epson authorized parts distributor.
http://www.epson.com/cgi-bin/Store/AboutEpsonConnection.jsp
---- or ----
Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find…” tool in the right column of the Epson Support home page.
http://www.epson.com/cgi-bin/Store/support/SupportIndex.jsp

Changes and additions shown in BLUE